


Parts Breakdown



Parts List

REF	PART #	DESCRIPTION
1	P0482001	SPINDLE PULLEY
2	P0482002	HEX NUT M33-1.5 LH
3	P0482003	PULLEY COVER
4	PS68M	PHLP HD SCR M6-1 X 10
5	P0482005	COVER KNOB M6-1
6	P6203	BEARING 6203ZZ
7	PVA25	V-BELT A-25
8	P0482008	MIDDLE PULLEY
9	PR54M	INT RETAINING RING 15MM
10	PVA40	V-BELT A-40
11	PR74M	INT RETAINING RING 45MM
12	P0482012	SHAFT ASSEMBLY
13	P0482013	MOTOR PULLEY
14	PSS01M	SET SCREW M6-1 X 10
15	P0482015	STRAIN RELIEF
16	P0482016	MOTOR CORD
17	P0482017	CORD WITH PLUG
18	P0482018	PULLEY INSERT
19	PR75M	INT RETAINING RING 66MM
20	P0482020	BEARING SPACER
21	P6007	BEARING 6007ZZ
22	PSS87M	SET SCREW M8-1.25 X 28
23	PN03M	HEX NUT M8-1.25
24	PLN09M	LOCK NUT M12-1.75
25	P0482025	COIL SPRING & CAP
26	PW22M	FLAT WASHER 65MM
27	G8988	PADDLE SWITCH
28	PS74M	PHLP HD SCR M4-.7 X 14
29	P0482029	LIGHT SWITCH
30	P0482030	SWITCH PLATE
31	PS74M	PHLP HD SCR M4-.7 X 14
32	PS09M	PHLP HD SCR M5-.8 X 10
33	P0482033	SWITCH BOX
34	PN03M	HEX NUT M8-1.25
35	P0482035	DEPTH STOP BRACKET
36	PS04M	PHLP HD SCR M8-1.25 X 20
37	P0482037	POST DEPTH STOP
38	P0482038	DEPTH STOP NUT M12-1.75
39	PS68M	PHLP HD SCR M6-1 X 10
40	P0482040	MOTOR BRACKET SUPPORT
41	PS09M	PHLP HD SCR M5-.8 X 10
42	P0482042	CORD CLAMP
43	P0482043	MOTOR BRACKET SUPPORT
44	PR05M	EXT RETAINING RING 15MM
45	P0482045	WING SCREW M10-1.5 X 32
46	PS39M	PHLP HD SCR M8-1.25 X 10
47	P0482047	ADJUSTING LEVER
48	PR02M	EXT RETAINING RING 14MM
49	P0482049	LEVER SHAFT
50	PB07M	HEX BOLT M8-1.25 X 25
51	P0482051	MOTOR PLATE
52	PLW05M	LOCK WASHER 12MM
53	PN09M	HEX NUT M12-1.75

REF	PART #	DESCRIPTION
54	P0482054	MOTOR
55	PN03M	HEX NUT M8-1.25
56	P0482056	RUBBER SEAL
57	P0482057	JUNCTION BOX
58	PS05M	PHLP HD SCR M5-.8 X 8
59	PS17M	PHLP HD SCR M4-.7 X 6
60	PSS13M	SET SCREW M10-1.5 X 12
61	PS09M	PHLP HD SCR M5-.8 X 10
62	P0482062	LAMP BRACKET
63	P0482063	SPACER
64	P0482064	PINION SHAFT
65	P0482065	DOWNFEED HANDLE M10-1.75
66	P0482066	DOWNFEED KNOB M10-1.75
67	PN41M	HEX NUT M25-2 LH
68	P6005	BEARING 6005ZZ
69	P0482069	QUILL BASKET
70	P0482070	QUILL
71	P51107	THRUST BEARING 51107
72	P6007	BEARING 6007ZZ
73	P0482073	SPINDLE
74	P0482074	DRIFT KEY
75	P0482075	ARBOR MT4/JT3
76	G8583	KEYLESS CHUCK 5/8" / JT3
77	P0482077	RACK
78	PS14M	PHLP HD SCR M6-1 X 12
79	P0482079	RACK COLLAR
80	P0482080	COLUMN
81	P0482081	TABLE BRACKET
82	P0482082	CORD PROTECTOR
83	P0482083	GEAR SHAFT
84	P0482084	CORD FOR LAMP
85	PB03M	HEX BOLT M8-1.25 X 16
86	P0482086	ADJUSTMENT HANDLE
87	P0482087	COLUMN LOCK HANDLE
88	P0482088	ELEVATING WORM
89	P0482089	HELICAL GEAR
90	P0482090	ZERO SCALE
91	P0482091	TABLE
92	PN32M	HEX NUT M14-2
93	PW10M	FLAT WASHER 14MM
94	P0482094	ARM STUD M14-2 X 63
95	PB33M	HEX BOLT M12-1.75 X 50
96	PLW05M	LOCK WASHER 12MM
97	P0482097	BASE FLANGE
98	P0482098	BASE
99	PLABEL-11	SAFETY GLASSES 2" X 3-5"/16"
100	P0482100	DOOR CLOSED HORIZONTAL
101	PLABEL-14	ELECTRICITY
102	P0482102	MACHINE ID LABEL
103	P0482103	SPEED CHART
104	PAW03M	HEX WRENCH 3MM
105	PAW05M	HEX WRENCH 5MM
106	P0482106	CHUCK GUARD ASSEMBLY

