# G1023SL (All) Main Parts



# G1023SL (All) Main Parts

| REF | PART # | DESCRIPTION |
|---|---|---|
| 1 | P1023SL001 | CABINET |
| 1A | P1023SL001A | LOWER PANEL |
| 2A | P1023SL002A | SCALE |
| 3 | PHTEK4 | TAP SCREW #10 X 3/8 |
| 4 | P1023SL004 | MOTOR COVER |
| 5 | P1023SL005 | CORD CLAMP |
| 6A | PS24 | PHLP HD SCR #8-32 X 3/8 |
| 6B | PN14 | HEX NUT #8-32 |
| 7 | P1023SL007 | LATCH |
| 58 | P1023SL058 | CORD CLAMP |
| 58A | P1023SL058A | CORD CLAMP PLATE |
| 58B | P1023SL058B | CORD CLAMP PLATE |
| 79 | PSS07 | SET SCREW 1/4-20 X 1/2 |
| 80 | P1023SL080 | STANDARD TABLE INSERT |
| 80A | P1023SL080A | DADO TABLE INSERT |
| 81 | P1023SL081 | TABLE |
| 82 | PLW04 | LOCK WASHER 3/8 |
| 83 | PB24 | HEX BOLT 3/8-16 X 1-1/4 |
| 83-1 | PB18 | HEX BOLT 3/8-16 X 1" |
| 84L | P1023SL084L | LEFT EXTENSION WING |
| 84R | P1023SL084R | RIGHT EXTENSION WING |
| 85 | PW02 | FLAT WASHER 3/8 |
| 86 | PSB16 | CAP SCREW 3/8-16 X 3/4 |
| 87 | P1023SL087 | MAG SWITCH (3HP, 1-PH) |
| 87 | P1023SLWX087 | MAG SWITCH (5HP, 1-PH) |
| 87 | P1023SLWX3087 | MAG SWITCH (5HP, 220V, 3-PH) |
| 87S | P1023SLWX3087S | MAG SWITCH (5HP, 440V, 3-PH) |
| 87A | PS31 | PHLP HD SCR 10-24 X 1-3/4 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 87B | PN07 | HEX NUT 10-24 |
| 87C | P1023SL087C | MOTOR CORD (G1023SL/X/W) |
| 87C | P1023SLWX087C | MOTOR CORD (G1023SLWX) |
| 87C | P1023SLWX3087C | MOTOR CORD (G1023SLWX3) |
| 87D | P1023SL087D | POWER CORD (G1023SL/X/W) |
| 87D | P1023SLWX087D | POWER CORD (G1023SLWX) |
| 87D | P1023SLWX3087D | POWER CORD (G1023SLWX3) |
| 87G | P1023SL087G | GROMMET |
| 87H | P1023SL087H | WIRE NUT |
| 88 | P1023SL088 | SWITCH PLATE |
| 88A | PFH25 | FLAT HD SCR 5/16-18 X 1" |
| 88B | PW07 | FLAT WASHER 5/16 |
| 88C | PN02 | HEX NUT 5/16-18 |
| 90A | P1023SL090A | G1023SL MACHINE ID LABEL |
| 90A | P1023SLX090A | G1023SLX MACHINE ID LABEL |
| 90A | P1023SLW090A | G1023SLW MACHINE ID LABEL |
| 90A | P1023SLWX090A | G1023SLWX MACHINE ID LABEL |
| 90A | P1023SLWX3090A | G1023SLWX3 MACHINE ID LABEL |
| 91 | P1023SL091 | DUST HOSE ADAPTER |
| 104 | PW03 | FLAT WASHER #10 |
| 154 | P1023SL154 | SWITCH PLATE BRACE |
| 155 | P1023SL155 | MOTOR BRACE |
| 211 | G8588 | LOGO PLATE |
| 212 | PLABEL-12A | READ MANUAL LABEL |
| 213 | PLABEL-11 | SAFETY GLASSES LABEL |
| 218 | PLABEL-14 | ELECTRICITY LABEL |
| 219 | PLABEL-33 | UNPLUG TABLE SAW LABEL |

## ⚠WARNING

**Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine MUST maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, REPLACE that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.**

# G1023SL (All) Arbor/Motor Parts



# G1023SL (All) Arbor/Motor Parts

| REF | PART # | DESCRIPTION |
|---|---|---|
| 8A | P1023SL008A | LOCK KNOB |
| 9B | P1023SL009B | HANDLE |
| 10A | P1023SL010A | HANDWHEEL |
| 11 | PSS03 | SET SCREW 1/4-20 X 3/8 |
| 12 | PSB65 | CAP SCREW 10-24 X 2" |
| 12A | PLW03 | LOCK WASHER #10 |
| 13 | P1023SL013 | POINTER BRACKET |
| 14A | PW07 | FLAT WASHER 5/16 |
| 14B | PS35 | PHLP HD SCR 5/16-18 X 3/8 |
| 15A | P1023SL015A | POINTER ADAPTER |
| 15B | PS23 | PHLP HD SCR 8-32 x 1/4 |
| 15C | P1023SL015C | POINTER |
| 16 | P1023SL016 | FRNT TRUNNION BRACKET |
| 16A | P1023SL016A | GUIDE BLOCK |
| 16B | PSB05 | CAP SCREW 1/4-20 X 3/4 |
| 16C | PW06 | FLAT WASHER 1/4 |
| 17 | P1023SL017 | SHIELD PLATE |
| 18 | PS35 | PHLP HD SCRW 5/16-18 X 3/4 |
| 19 | PSB26 | CAP SCREW 3/8-16 X 11/2 |
| 20 | PLW04 | LOCK WASHER 3/8 |
| 21 | PN08 | HEX NUT 3/8-16 |
| 22 | PSS03 | SET SCREW 1/4-20 X 3/8 |
| 23 | P1023SL023 | WORM GEAR |
| 24 | P1023SL024 | COLLAR |
| 25 | PSS05 | SET SCREW 5/16-18 X 1/4 |
| 26 | P1023SL026 | TILT SHAFT |
| 26A | P1023SL026A | BRASS WASHER 3/4 |
| 27 | P1023SL027 | PIN |
| 27A | P1023SL027A | BEARING LOAD SPRING |
| 28 | PK02M | KEY 5 X 5 X 40 |
| 29A | P1023SL029A | GEARED TRUNNION |
| 29B | P1023SL029B | BUSHING |
| 30 | PN02 | HEX NUT 5/16-18 |
| 30A | PSB08 | CAP SCREW 5/16-18 X 1-1/2 |
| 30B | P1023SL030B | SPACER |
| 31 | PB03 | HEX BOLT 5/16-18 X 1 |
| 32 | P1023SL032 | FLANGE |
| 33 | P1023SL033 | SHAFT |
| 35A | P1023SL035A | GEAR BEARING HOUSING |
| 35B | P1023SL035B | HOUSING CAP |
| 35C | PS06 | PHLP HD SCR 10-24 X 3/8 |
| 35D | PLW03 | LOCK WASHER #10 |
| 36 | PSB26 | CAP SCREW 3/8-16 X 1-1/2 |
| 37A | PLW04 | LOCK WASHER 3/8 |
| 37B | PK03 | KEY 1/4 X 1/4 X 45 |
| 38 | P1023SL038 | BEARING 6203-2RS |
| 40 | P1023RL138 | THIN LOCK NUT 5/8-18 LH |
| 41 | P1023SL041 | COLLAR |
| 42 | P1023SL042 | ARBOR PULLEY |
| 43 | PSS10 | SET SCREW 1/4-20 X 5/8 |
| 43A | PSS06 | SET SCREW 1/4-20 X 3/4 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 44 | PK02M | KEY 5 X 5 X 40L |
| 45 | P1023SL045 | BLADE ARBOR |
| 47 | P1023SL047 | ARBOR FLANGE |
| 48 | P1023SL048 | ARBOR NUT |
| 50 | P1023SL050 | MOTOR FRAME SUPPORT |
| 51 | P1023SL051 | CLIP |
| 52 | P1023SL052 | PIVOT PIN |
| 53 | PSB14 | CAP SCREW 3/8-16 X 1" |
| 54 | P1023SL054 | (3) V-BELTS M-25 3L250 MATCHED |
| 55 | P1023SL055 | MOTOR PULLEY |
| 56 | P1023SL056 | MOTOR 3HP, 220V, 1-PH |
| 56 | P1023SLWX056 | MOTOR 5 HP, 220V, 1-PH |
| 56 | P1023SLWX3056 | MOTOR 5 HP, 220V/440V, 3-PH |
| 56A | P1023SL056A | MOTOR PLATE |
| 56-1 | P1023SL056-1 | MOTOR FAN (3HP, 1-PH) |
| 56-1 | P1023SLWX056-1 | MOTOR FAN (5HP, 1-PH) |
| 56-1 | P1023SLWX3056-1 | MOTOR FAN (5HP, 3-PH) |
| 56-2 | P1023SL056-2 | MOTOR FAN COVER |
| 56-2 | P1023SLWX056-2 | MOTOR FAN COVER (5HP, 1-PH) |
| 56-2 | P1023SLWX3056-2 | MOTOR FAN COVER (5HP, 3-PH) |
| 56-3 | P1023SL056-3 | CAPACITOR COVER (3HP, 1-PH) |
| 56-3 | P1023SLWX056-3 | CAPACITOR COVER (5HP, 1-PH) |
| 56-5 | PC600 | START CAP 600MF 125V (3HP, 1-PH) |
| 56-5 | P1023SLWX056-5 | START CAP 400MF 125V (5HP, 1-PH) |
| 56-6 | P1023SL056-6 | WIRING BOX (3HP, 1-PH) |
| 56-6 | P1023SLWX056-6 | WIRING BOX (5HP, 1-PH) |
| 56-6 | P1023SLWX3056-6 | WIRING BOX (5HP, 3-PH) |
| 56-7 | P1023SLWX056-7 | CAPACITOR COVER |
| 56-8 | P1023SLWX056-8 | RUN CAP 50UF 350V (5HP, 1-PH) |
| 61 | PW07 | FLAT WASHER 5/16 |
| 63A | P1023SL063A | REAR TRUNNION |
| 63B | P1023SL063B | BUSHING |
| 64 | PRP07 | ROLL PIN 5/16 X 1 |
| 65 | PSB14 | CAP SCREW 3/8-16 X 1" |
| 66 | PLW04 | LOCK WASHER 3/8 |
| 68 | P1023SL068 | SHAFT |
| 69 | PLN05 | LOCK NUT 3/4-16 |
| 70 | P1023SL070 | REAR TRUNNION BRACKET |
| 89 | PK02M | KEY 5 X 5 X 40MM |
| 92 | PW07 | LOCK WASHER 5/16 |
| 94 | P1023SL094 | DUST DEFLECTOR |
| 95 | P1023SL095 | SPECIAL SCREW 5/16-18 X 1-1/4 |
| 95A | PSS08 | SET SCREW 5/16-18 X 1/2 |
| 95B | PN02 | HEX NUT 5/16-18 |
| 99 | PB32 | HEX BOLT 5/16-18 X 5/8 |
| 85 | PW02 | FLAT WASHER 3/8 |
| 216 | PAW08M | HEX WRENCH 8MM |
| 217 | P1023SL217 | ARBOR WRENCH |
| 220 | PAW03M | HEX WRENCH 3MM |
| 221 | PAW04M | HEX WRENCH 4MM |
| 222 | P1023SL222 | FLAT WRENCH 22MM |

# G1023SL (All) Miter Gauge & Blade Guard



# G1023SL (All) Miter Gauge & Blade Guard

| REF | PART # | DESCRIPTION |
|---|---|---|
| 57 | PB15 | HEX BOLT 5/16-18 X 3/8 |
| 57A | PW07 | FLAT WASHER 5/16 |
| 60 | PB07 | HEX BOLT 5/16-18 X 3/4 |
| 61 | PW07 | FLAT WASHER 5/16 |
| 62 | P1023SL062 | BRACKET |
| 72 | P1023SL072 | SHAFT |
| 73 | P1023SL073 | UPPER GUARD BRACKET |
| 74 | P1023SL074 | LOWER GUARD BRACKET |
| 140 | PB11 | HEX BOLT 5/16-18 X 1-1/2 |
| 141 | PW07 | FLAT WASHER 5/16 |
| 142 | PLW01 | LOCK WASHER 5/16 |
| 143 | PN02 | HEX NUT 5/16-18 |
| 144 | PB03 | HEX BOLT 5/16-18 X 1" |
| 145 | PSS02 | SET SCREW 5/16-18 X 3/8 |
| 300 | P1023SL300 | BLADE GUARD ASSEMBLY |
| 301 | P1023SL301 | USE GUARD LABEL |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 400 | P1023400 | COMPLETE MITER GAUGE |
| 401 | P1023401A | HANDLE 5/16-18 X 1-1/4 |
| 402 | PW07 | FLAT WASHER 5/16 |
| 403 | P1023403 | MITER GAUGE BODY |
| 404 | P1023404A | MITER BAR |
| 405 | P1023405 | SPECIAL WASHER |
| 406 | PFH09 | FLAT HD SCR 1/4-20 X 5/16 |
| 407 | PN07 | HEX NUT 10-24 |
| 408 | PSS32 | SET SCREW 10-24 X 3/4 |
| 409 | PSS34 | SET SCREW 10-24 X 1/2 |
| 410 | P1023410 | STOP |
| 411 | P1023411 | POINTER |
| 412 | P1023412 | SCALE |
| 413 | PSS31 | SET SCREW 10-24 X 5/8 |
| 414 | PRP50M | ROLL PIN 1.5 X 13 |
| 415 | P1023SL415 | MITER HINGE PIN |

## ⚠WARNING

**Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine MUST maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, REPLACE that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.**

# G1023SL (All) Fence




| REF | PART # | DESCRIPTION |
|---|---|---|
| 501 | P1023SL501 | FENCE LOCKING TAB |
| 502 | P1023SL502 | KNOB |
| 503 | P1023SL503 | BEARING PAD |
| 504 | P1023SL504 | LOCKING LEVER |
| 508 | P1023SL508 | FENCE BODY |
| 508A | P1023SL508A | FENCE FACING |
| 512 | P1023SL512 | MAGNIFIED CURSOR |
| 517 | PB88 | HEX BOLT 1/4 - 20 X 1-3/4 |
| 520 | PB25 | HEX BOLT 3/8-16 X 1-3/4 |
| 522 | PS06 | PHLP HD SCR 10-24 X 3/8 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 523 | PSS48 | SET SCREW 3/8-16 X 5/16 |
| 527 | PLN02 | LOCK NUT 1/4-20 |
| 528 | PLN01 | LOCK NUT 3/8-16 |
| 530 | PW03 | FLAT WASHER #10 |
| 531 | PW06 | FLAT WASHER 1/4 |
| 532 | PW02 | FLAT WASHER 3/8 |
| 544 | P1023SL544 | MAGNET |
| 545 | PS43 | PHLP HD SCR 10-24 x 1/2 |
| 550 | P1023SL550 | FENCE WARNING LABEL |

## ⚠WARNING

**Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine MUST maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, REPLACE that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.**

# G1023SL, W, WX, WX3 Fence Rails




| REF | PART # | DESCRIPTION |
|---|---|---|
| 514 | P1023SL514 | SCALE |
| 515 | P1023SL515 | FRONT RAIL TUBE |
| 516 | PB05 | HEX BOLT 1/4-20 X 3/4 |
| 516A | P1023SL516A | FRONT RAIL SUPPORT |
| 517A | P1023SL517A | REAR RAIL |
| 518 | PB18 | HEX BOLT 3/8-16 X 1 |
| 526 | PFH21 | FLAT HD SCR 10-24 X 3/4 |
| 531 | PW06 | FLAT WASHER 1/4 |
| 532 | PW02 | FLAT WASHER 3/8 |
| 533 | PW06 | FLAT WASHER 1/4 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 536 | P1023SL536 | L-BRACKET |
| 537 | P1023SL537 | LOCKING PLATE |
| 538 | PB26 | HEX BOLT 1/4-20 X 1-1/2 |
| 539 | PW06 | FLAT WASHER 1/4 |
| 540 | PN05 | HEX NUT 1/4-20 |
| 541 | PB07 | HEX BOLT 5/16-18 X 3/4 |
| 542 | PW07 | FLAT WASHER 5/16 |
| 543 | PN02 | HEX NUT 5/16-18 |
| 551 | P1023SL551 | RAIL WARNING LABEL |

# G1023SLW, X, X3 Router Table & Legs Parts




| REF | PART # | DESCRIPTION |
|---|---|---|
| 601 | P1023SLW601 | ROUTER TABLE EXT WING |
| 602 | P1023SLW602 | TABLE INSERT 29MM |
| 603 | P1023SLW603 | TABLE INSERT 60MM |
| 604 | P1023SLW604 | ROLL PIN 3 X 9 |
| 606 | P1023SLW606 | EXTENSION LEG |
| 607 | P1023SLW607 | ADJUSTABLE FOOT |
| 608 | PN06 | HEX NUT 1/2-12 |
| 609 | P1023SLW609 | MOTOR CLAMP PIECE |
| 610 | P1023SLW610 | STUD |
| 611 | PB10 | HEX BOLT 1/4-20 X 2 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 612 | PN05 | HEX NUT 1/4-20 |
| 612A | PB31 | HEX BOLT 1/4-20 X 1 |
| 613 | PB24 | HEX BOLT 3/8-16 X 1-1/4 |
| 614 | PLW04 | LOCK WASHER 3/8 |
| 615 | PW02 | FLAT WASHER 3/8 |
| 616 | PN08 | HEX NUT 3/8-16 |
| 617 | PFH05 | FLAT HD SCR 1/4-20 X 3/4 |
| 618 | PW06 | FLAT WASHER 1/4 |
| 619 | PN05 | HEX NUT 1/4-20 |