


Column Parts Breakdown




Column Parts List

REF	PART #	DESCRIPTION
1	P3616001	BASE
2	P3616002	COLUMN (G3616)
2	P3617002	COLUMN (G3617)
3	P3616003	ELEVATING SCREW HOUSING
4	PLW06M	LOCK WASHER 10MM
5	PB116M	HEX BOLT M10-1.5 x 45
6	P3616006	CONNECT TUBE
7	PS38M	PHLP HD SCR M4-.7 x 10
8	PB131M	HEX BOLT M16-2 X 65
9	PLW10M	LOCK WASHER 16MM
10	P3616010	COLLAR
11	PSB31M	CAP SCREW M8-1.25 x 25
12	P3616012	HOLD SUPPORT
13	PSB77M	CAP SCREW M12-1.75 X 30
14	P3616014	AROUND BRACKET
15	P3616015	FEED SHAFT
16	P3616016	COLLAR
17	P3617017	CLAMP BOLT M12-1.75 X 58 X 25
18	P3616018	CLAMP BLOCK
19	P3616019	GIB
20	PFH42M	FLAT HD SCR M8-1.25 x 40
21	P3616021	OVERARM
22	P3616022	COVER
23	PS08M	PHLP HD SCR M5-.8 X 12
24	P3616024	COVER
25	PS08M	PHLP HD SCR M5-.8 X 12
26	P3616026	HOLD BRACKET
27	P3616027	GEAR
28	PSB122M	CAP SCREW M16-2 X 50
29	PSB123M	CAP SCREW M16-2 X 60
30	P3616030	NOZZLE
31	P3616031	OIL CUP
32	PSB01M	CAP SCREW M6-1 x 16
33	PSB01M	CAP SCREW M6-1 x 16
34	P3616034	CONNECT TUBE
35	P3616035	HOLD BRACKET
36	PN13M	HEX NUT M16-2
37	PLW10M	LOCK WASHER 16MM
38	P3616038	T BOLT M16-2 X 63
39	PS08M	PHLP HD SCR M5-.8 X 12
40	P3616040	ELECTRIC PUMP
41	PB83M	HEX BOLT M6-1 X 16
42	P3616042	SUPPORT
43	P3616043	DUST COVER
44	PS08M	PHLP HD SCR M5-.8 X 12
45	P3616045	GIB
46	P3616046	ADJUST SCREW M8-1.25
47	PS08M	PHLP HD SCR M5-.8 X 12

REF	PART #	DESCRIPTION
48	P3616048	WIPER PLATE
49	P3616049	WIPER PLATE
50	P3616050	WIPER PLATE
51	P3616051	KNEE
52	P3616052	CLAMP BLOCK
53	P3616053	CLAMP BOLT M10-1.5 x 58 X 25
54	P3616054	HOIST DESCEND LEAD SCREW
55	P3616055	CIRCULAR NUT
56	P3616056	CONICAL GEAR
57	PK95M	KEY 6 X 6 X 10
58	P3616058	BALL BEARING 25 X 42 X 11
59	P3616059	ADJUST WASHER
60	P3616060	COLLAR
61	P3616061	BALL BEARING 25 X 42 X 11
62	P3616062	HEX NUT DIA. 42 X 60MM
63	PSS16M	SET SCREW M8-1.25 X 10
64	PK09M	KEY 8 X 8 X 36
65	P3616065	CONICAL GEAR
66	PK34M	KEY 5 X 5 X 20
67	PW19M	FLAT WASHER 42 x 25 x 3MM
68	P3616068	COLLAR
69	PSS80M	SET SCREW M8-1.25 x 15
70	P3616070	SHAFT
71	P3616071	COLLAR
72	PSB114M	CAP SCREW M6-1 x 22
73	P3616073	BALL BEARING 25 X 42 X 11
74	P3616074	SCALE RING
75	P3617075	KNURLED THUMB SCR M6-1 X 10
76	P3616076	COLLAR
77	P3616077	HANDLE
78	P3617078	LIFT BAR (G3617)
79	P3617079	TOOLHOLDER (G3617)
80	P3617080	CUTTER BAR COLLAR (G3617)
81	P3617081	SUPPORT (G3617)
82	P3617082	SPECIAL BOLT M16-2 X 218 (G3617)
83	P3617083	COLLAR (G3617)
84	P3617084	SPECIAL NUT M22 X 1.5MM (G3617)
85	PSS06M	SET SCREW M8-1.25 x 16 (G3617)
86	P3617086	OIL CUP (G3617)
87	PW08M	FLAT WASHER 16MM (G3617)
88	PN13M	HEX NUT M16-2 (G3617)
89	P3617089	BEHIND COVER (G3617)
90	P3617090	HINGE (G3617)
91	PFH25M	FLAT HD SCR M4-.7 X 12 (G3617)
92	PS96M	PHLP HD SCR M10-1.5 x 8 (G3617)
93	P3616093	VERTICAL SPINDLE SPEEDS LABEL
94	P3617094	HORZ SPINDLE SPEEDS LABEL
95	G8588	GRIZZLY CAST IRON LOGO PLATE



Rotary Table Parts Breakdown




Rotary Table Parts List

REF	PART #	DESCRIPTION
101	P3616101	HANDLE
102	P3616102	HANDLE COLLAR
103	PN09M	HEX NUT M12-1.75
104	PK96M	KEY 3 X 3 X 20
105	PLW05M	LOCK WASHER 12MM
106	P3616106	HAND WHEEL
107	P3616107	SCALE RING
108	PSB04M	CAP SCREW M6-1 X 10
109	P3616109	BALL BEARING 17 X 30 X 9
110	PSB61M	CAP SCREW M10-1.5 x 20
111	P3616111	SUPPORT
112	P3616112	OIL CUP
113	P3616113	SCREW BRACKET
114	P3616114	DOG
115	PSB01M	CAP SCREW M6-1 X 16
116	P3616116	OIL CUP
117	P3617117	ROTARY BRACKET
118	P3616118	TABLE (G3616)
118	P3617118	TABLE (G3617)
119	P3616119	SPECIAL NUT 1" (LEAD NUT)
120	P3617120	LIMIT ASSEMBLY
121	PN09M	HEX NUT M12-1.75
122	PW06M	FLAT WASHER 12MM
123	P3616123	T BOLT M12-1.75 X 45
124	P3616124	SHAFT MOUNT
125	P3616125	SHAFT
126	P3616126	GIB

REF	PART #	DESCRIPTION
127	P3616127	ADJUST SCREW M8-1.25
128	P3616128	LONG LEAD SCREW (G3616)
128	P3617128	LONG LEAD SCREW (G3617)
129	P3617129	WAY COVER
130	PS68M	SLOT SCREW M6-1 X 12
131	P3616131	FLAT HD SCR M8-1.25 x 20
132	P3616132	SPECIAL WASHER 32 X 9 X 1.5
133	P3616133	SADDLE
134	P3616134	CLAMP BOLT M10-1.5 x 58 X 25
135	P3616135	CARRIAGE CLAMP BLOCK
136	P3616136	CLAMP BLOCK
137	P3616134	CLAMP BOLT M10-1.5 x 58 X 25
138	PB03M	HEX BOLT M8-1.25 X 16
139	P3616139	WIPER PLATE
140	PS08M	PHLP HD SCR M5-.8 X 12
141	P3617141	CROSS HEAD LEAD SCREW
142	P3616142	GIB
143	P3617143	SPECIAL NUT 1"
144	P3616144	ADJUST SCREW M8-1.25
145	P3617145	BALL BEARING 17 X 30 X 9
146	P3616146	SUPPORT
147	PSB02M	CAP SCREW M6-1 x 20
148	P3616148	OIL COVER
149	PS05M	PHLP HD SCR M5-.8 x 8
150	P3616150	CONNECT TUBE
151	P3616151	COMPLETE MILLING VISE



Head Parts Breakdown




Head Parts List

REF	PART #	DESCRIPTION
201	P3616201	SPINDLE BOX
202	P3616202	MOTOR BASE
203	P3616203	LEFT COVER
204	P3616204	RIGHT COVER
205	P3616205	PULLEY COVER
206	PS26M	SLOT HEAD SCREW M6-1 x 20
207	P3616207	KNURLED SCREW M6-1 X 10
208	PB74M	HEX BOLT M10-1.5 x 20
209	PLW06M	LOCK WASHER 10MM
210	P3616210	CENTER PULLEY
211	P3616211	CENTER PULLEY SHAFT
212	PB07M	HEX BOLT M8-1.25 x 25
213	PW10M	FLAT WASHER 14MM
214	P3616214	MOTOR
214-1	P3616214-1	MOTOR FAN COVER
214-2	P3616214-2	MOTOR FAN
214-3	P3616214-3	CAPACITOR BOX
214-4	PC150A	S CAPACITOR 150MFD 250VAC
214-5	PC20A	R CAPACITOR 20MFD 400VAC
215	P3616215	HANDLE
216	PB07M	HEX BOLT M8-1.25 x 25
217	PK41M	KEY 8 X 8 X 40
218	P3616218	MOTOR PULLEY
219	PSS04M	SET SCREW M6-1 X 12
220	P3616220	WORM GEAR
221	PSB13M	CAP SCREW M8-1.25 x 30
222	P3616222	T BOLT M16-2 X 63
223	PN13M	HEX NUT M16-2
224	P3616224	FEED SHAFT
225	PK09M	KEY 8 X 8 X 36
226	P3616226	HANDLWHEEL GEAR BOX
227	PSB14M	CAP SCREW M8-1.25 x 20
228	P3616228	BEVEL GEAR
229	PR15M	EXT RETAINING RING 30MM
230	P3616230	COMPRESSION SPRING
231	P3616231	SCALE RING
232	P3616232	HANDLE BRACKET HUB
233	P3616233	COVER
234	PB133M	HEX BOLT M16-2 X 90
235	P3617235	HANDLE BAR
236	P3617236	FEED SHAFT KNOB M12-1.75
237	P3616237	HANDLE
238	P3616238	HANDLE COLLAR KNOB
239	P3616239	SCALE
240	P3616240	RIVET
241	P3616241	WORM GEAR
242	P3616242	BALL BEARING 15 X 28 X 9

REF	PART #	DESCRIPTION
243	P3616243	SMALL COVER
244	PSB26M	CAP SCREW M6-1 X 12
245	P3616245	BALL BEARING 15 X 28 X 9
246	P3616246	COLLAR
247	P3616247	SCALE RING
248	P3617248	HANDLE WHEEL
249	P3617249	HANDLE COLLAR
250	P3617250	HANDLE
251	PN26M	ACORN NUT M12-1.75
252	PK97M	KEY 4 X 4 X 14
253	P3616253	CLAMP BLOCK
254	P3616254	CLAMP BLOCK
255	P3616255	CLAMP HANDLE
257	P3616257	SPRING SEAT
258	PS11M	SCREW M6-1 X 16
259	PSS19M	SET SCREW M8-1.25 x 30
260	P3616260	SPRING PLATE
261	P3616261	SPRING CAP
262	PS17M	PHLP HD SCR M4-.7 x 6
263	PVB30	V-BELT B-30 5L300
264	P3616264	SLOTTED LOCK NUT M50 X 1.5MM
265	P3616265	SPINDLE PULLEY
266	P3616266	SPRING SLEEVE
267	P3616267	COLLAR
268	PSB01M	CAP SCREW M6-1 X 16
269	PR67M	INT RETAINING RING 75MM
270	P6009ZZ	BALL BEARING 6009ZZ
271	P3616271	COLLAR
272	P6009ZZ	BALL BEARING 6009ZZ
273	PR67M	INT RETAINING RING 75MM
274	PR56M	EXT RETAINING RING 45MM
275	P3616275	PULLEY NUT
276	PLW13M	LOCK WASHER 40MM
277	P6003	BALL BEARING 6003ZZ
278	P3616278	QUILL
279	P3616279	BALL BEARING 50 X 80 X 20
280	P3616280	DUST COVER
281	P3616281	SPINDLE
282	P3616282	ARBOR R-8 X
283	P3616283	DRILL CHUCK
284	P3616284	WEDGE SHIFTER
285	P3616285	G3616 MACHINE ID LABEL
285	P3617285	G3617 MACHINE ID LABEL
286	P3616286	SECONDARY WARNINGS LABEL
287	P3616287	PROPER TRAINING NOTICE
288	P3616288	BELT GUARD LABEL



G3617 Horizontal Spindle Parts Breakdown




G3617 Horizontal Spindle Parts List

REF	PART #	DESCRIPTION
303	PSB31M	CAP SCREW M8-1.25 x 25
304	P3617304	OIL CUP
305	P3617305	COVER
306	P3617306	SPINDLE
307	P3617307	BALL BEARING 55 X 90 X 23
308	P3617308	COLLAR
309	P3617309	BALL BEARING 40 X 90 X 25
310	P3617310	SPECIAL WASHER 52 X 4
311	P3617311	FLAT WASHER 39MM
312	P3617312	SLOTTED LOCK NUT M39 X 1.5MM
313	P3617313	COVER
314	PSB31M	CAP SCREW M8-1.25 x 25
315	P3617315	OIL CUP
316	P3617316	SPINDLE PULLEY
317	PK90M	KEY 10 X 10 X 25
318	PR12M	EXT RETAINING RING 35MM
319	PVA30	V-BELT A-30 4L300
320	PK42M	KEY 6 X 6 X 30
321	PR09M	EXT RETAINING RING 20MM
322	P3617322	WHEEL
323	P6003	BALL BEARING 6003ZZ
324	P3617324	BEARING 37MM
325	P6003	BALL BEARING 6003ZZ
326	P3617326	COLLAR
328	P3617328	SMALL SHAFT
329	P3617329	COLLAR
330	P3617330	SUPPORT
331	PSB02M	CAP SCREW M6-1 x 20
332	PB13M	HEX BOLT M10-1.5 x 80
333	PN02M	HEX NUT M10-1.5
334	PR25M	INT RETAINING RING 47MM
335	PR11M	EXT RETAINING RING 25MM
336	P3617336	SPECIAL NUT M64 X 2
337	PR25M	INT RETAINING RING 47MM
338	P3617338	PULLEY
339	PR11M	EXT RETAINING RING 25MM
340	P3617340	KEY 8 X 8 X 50
341	P3617341	MOTOR BASE
342	PSB124M	CAP SCREW M12-1.75 X 80

REF	PART #	DESCRIPTION
343	PN13M	HEX NUT M16-2
344	PW08M	FLAT WASHER 16MM
345	PW08M	FLAT WASHER 16MM
346	P3617346	SMALL SHAFT
347	P3617347	CONNECT
349	P6003	BALL BEARING 6003ZZ
350	P3617350	COLLAR
351	P6003	BALL BEARING 6003ZZ
352	PR18M	EXT RETAINING RING 17MM
353	PR21M	INT RETAINING RING 35MM
354	P3617354	PULLEY
355	PVA31	V-BELT A-31 4L310
356	P3617356	ADJUST SCREW M8-1.25
357	P3617357	SUPPORT
358	PSB02M	CAP SCREW M6-1 x 20
359	P3617359	SPECIAL NUT M8-1.25
360	P3617360	MOTOR
360-1	P3617360-1	MOTOR FAN COVER
360-2	P3617360-2	MOTOR FAN
360-3	P3617360-3	R CAPACITOR COVER
360-4	PC020B	R CAPACITOR 20MFD 450VAC
360-5	P3617360-5	S CAPACITOR COVER
360-6	PC150A	S CAPACITOR 150MFD 250VAC
360-7	P3617360-7	WIRING BOX
361	PLW04M	LOCK WASHER 8MM
362	PB07M	HEX BOLT M8-1.25 x 25
363	P3617363	MOTOR WHEEL
364	PSS04M	SET SCREW M6-1 X 12
365	PK43M	KEY 8 X 8 X 45
366	PVA31	V-BELT A-31 4L310
385	P3617385	1" HORIZONTAL ARBOR
385-1	P3617385-1	1" ARBOR NUT
385-2	P3617385-2	1" ARBOR SLEEVE
385-3	P3617385-3	1" ARBOR SPACER
386	P3617386	1-1/4" HORIZONTAL ARBOR
386-1	P3617386-1	1-1/4" ARBOR NUT
386-2	P3617386-2	1-1/4" ARBOR SLEEVE
386-3	P3617386-3	1-1/4" ARBOR SPACER



Power Feed Parts Breakdown



Power Feed Parts List

REF	PART #	DESCRIPTION
401	P3616401	TOP HOUSING
402	PN20M	HEX NUT M32-2
403	PW20M	FLAT WASHER 35MM
404	P3616404	BEVEL GEAR
405	PW08M	FLAT WASHER 16MM
406	PLN09	LOCK NUT M12-1.75
407	P3616407	INNER RING 20/28
408	P3616408	NEEDLE BEARING
409	P3616409	CIRCUIT BREAKER SUPPORT
409-1	P3616409-1	CIRCUIT BREAKER
409-2	P3616409-2	CIRCUIT BREAKER COVER
409-3	PN09M	HEX NUT M12-1.75
410	P3616410	BUSHING BEARING
411	P3616411	LIGHT TRANSMITTER
412	P3616412	HEX SEAL BOOT
413	PN09M	HEX NUT M12-1.75
414	P3616414	LIFT FORK SHAFT
415	P3616415	CRESCENT RING
416	P3616416	BUSHING BEARING
417	P3616417	BOTTOM HOUSING
418	P3616418	SPECIAL SCREW
419	P3616419	POWER CORD
420	P3616420	CONTROL CORD
421	P3616421	CORD CLAMP
422	P3616422	LOCKING NUT
423	P3616423	BOTTOM COVER
424	PS38M	PHLP HD SCR M4-.7 X 10
425	PN04M	HEX NUT M4-.7
426	PS17M	PHLP HD SCR M4-.7 X 6
427	P3616427	ADAPTOR
428	P3616428	SPRING FOR TOP HOUSING
429	P3616429	BEARING MOUNT
430	PLW02M	LOCK WASHER 4MM
431	PRP76M	ROLL PIN 4 X 16
432	PSS79M	SET SCREW M4-.7 X 6
433	P3616433	LABEL
434	P3616434	ON/OFF SWITCH
434-1	PN09M	HEX NUT M12-1.75
435	P3616435	CAP OF ON/OFF SWITCH
436	PN09M	HEX NUT M12-1.75
437	P3616437	CAUTION LABEL
438	P3616438	LABEL
439	P3616439	LABEL
440	PS94M	PHLP HD SCR M5-.8 X 75
501	P3616501	MICRO SWITCH ASSY
501-1	P3616501-1	MICRO SWITCH HOLDER
501-2	P3616501-2	SWITCH ACTUATOR
501-3	P3616501-3	PIN ACTUATOR
501-4	P3616501-4	MICRO SWITCH

REF	PART #	DESCRIPTION
501-5	PS95M	PHLP HD SCR M3-.5 X 30
501-6	PN07M	HEX NUT M3-.5
501-7	P3616501-7	CAPACITOR
502-1	P3616502-1	CAM ASSEMBLY
502-2	PRP11M	ROLL PIN 2.5 X 16
503-1	P3616503-1	MOTOR FIELD ASSEMBLY
503-2	P3616503-2	ARMATURE ASSEMBLY
504	P3616504	BRUSH
505	P3616505	LIMIT SWITCH ASSEMBLY
505-1	P3616505-1	HOLD PLATE
505-1	PN07M	HEX NUT M3-.5
505-11	PS97M	PHLP HD SCR M3-.5 X 34
505-12	PS98M	PHLP HD SCR M3-.5 X 16
505-13	PS59M	PHLP HD SCR M3-.5 X 14
505-14	P3616505-14	MICRO SWITCH
505-15	P3616505-15	CRESCENT RING
505-2	P3616505-2	LIMIT SWITCH HOLDER
505-3	P3616505-3	LIMIT PLATE
505-4	P3616505-4	ACTUATOR
505-5	P3616505-5	SPRING
505-6	P3616505-6	LIMIT SWTCH GASKET
505-7	P3616505-7	ACTUATOR
505-8	P3616505-8	CONNECTING PLATE
505-9	PS12M	PHLP HD SCR M3-.5 X 6
506	P3616506	BRUSH HOLDER
506-1	P3616506-1	BRUSH CAP
507	P3616507	ON/OFF NAMPLATE
508	P3616508	MICRO SWITCH ASSEMBLY
508-1	P3616508-1	MICRO SWITCH HOLDER
508-2	P3616508-2	MICRO SWITCH
508-3	PN07M	HEX NUT M3-.5
508-4	PS59M	PHLP HD SCR M3-.5 X 14
509	P3616509	DRIVE GEAR ASSEMBLY
509-1	P3616509-1	DRIVE GEAR SHAFT
509-2	PRP37M	ROLL PIN 3 X 14
509-3	P80018	BALL BEARING 80018
509-4	P3616509-4	DRIVE GEAR
509-5	P3616509-5	SPACER
509-6	PR66M	INT RETAINING RING 25MM
510	P3616510	LIFT FORK ASSEMBLY
510-1	P3616510-1	DRIVING SHAFT
510-2	P3616510-2	SHAFT MOUNT
510-3	P3616510-3	SPRING
510-4	P3616510-4	CLUTCH
510-5	PW18M	FLAT WASHER 18MM
510-6	P3616510-6	BEARING COVER
510-7	P3616510-7	BEARING
510-8	PRP02M	ROLL PIN 3 X 16
510-9	PRP02M	ROLL PIN 3 X 16




Power Feed Parts List, continued

REF	PART #	DESCRIPTION
511-1	P3616511-1	LIFTFORK
511-2	P3616511-2	LIFTFORK RING
511-3	P3616511-3	PIN, LIFTFORK RING 3 X 14
512-1	P3616512-1	X CONTROL HANDLE ASSY
512-2	P3616512-2	Y,Z CONTROL HANDLE ASSY
512-3	P3616512-3	HANDLE KNOB M8-1.25
512-4	PSS04M	SET SCREW M6-1 X 12
512-5	P3616512-5	CONTROL HANDLE
513	P3616513	ZYTEL GEAR ASSEMBLY
513-1	P3616513-1	ZYTEL GEAR WITHOUT HUB
513-2	PW21M	FLAT WASHER 32MM
513-3	P3616513-3	HUB OF ZYTEL GEAR
513-4	P3616513-4	LOCK WASHER 38MM
513-5	PR29M	INT RETAINING RING 32MM
514-1	P3616514-1	POTENTIOMETER ASSEMBLY
514-2	P3616514-2	POTENTIOMETER RING
514-3	P3616514-3	POTENTIOMETER SARAIN
514-4	PW05M	FLAT WASHER 4MM
514-5	PS17M	PHLP HD SCR M4-.7 X 6
515	P3616515	RAPID SWITCH BUTTON
515-1	P3616515-1	RAPID SWITCH PLUNGER

REF	PART #	DESCRIPTION
515-2	P3616515-2	RAPID SWITCH HOUSING
515-3	P3616515-3	SPRING FOR RAPID SWITCH
515-4	PEC13M	E-CLIP 5MM
516	P3616516	CIRCUIT BOARD ASSEMBLY
517	P3616517	CIRCUIT BOARD INSULATOR
518	P3616518	TRAVEL STOP ASSEMBLY
518-1	P3616518-1	TRAVEL STOP
518-2	P3616518-2	TRAVEL STOP BASE
518-3	P3616518-3	TRAVEL STOP SHAFT
518-4	P3616518-4	SPRING
518-5	PB07M	HEX BOLT M8-1.25 X 25
518-6	P3616518-6	SPACER
518-7	PR39M	EXT RETAINING RING 8MM
519	P3616519	SPEED CONTROL KNOB ASSEMBLY
519-1	P3616519-1	SPEED CONTROL KNOB M6-1
519-2	P3616519-2	SPEED CONTROL LABEL
519-3	PSS49M	SET SCREW M4-.7 X 16
512-1-1	P3616512-1-1	X CONTROL HANDLE DISC
512-1-2	P3616512-1-2	Y,Z CONTROL HANDLE DISC
514-1-1	PN03M	HEX NUT M8-1.25
514-1-2	P3616514-1-2	POTENTIOMETER WASHER



G3616 Electrical Parts Breakdown




G3616 Electrical Parts List

REF	PART #	DESCRIPTION
601	P3616601	HALOGEN LAMP
601-1	P3616601-1	BULB
601-2	P3616601-2	BULB COVER
601-3	P3616601-3	BULB COVER RETAINER
601-4	PS55M	PHLP HD SCR M3-.5 X 10
602	PSB01M	CAP SCREW M6-1 x 16
603	P3616603	LAMP MOUNTING BRACKET
604	PLW03M	LOCK WASHER 6MM
605	PN01M	HEX NUT M6-.8
606	PSB01M	CAP SCREW M6-1 x 16
607	PLW01M	LOCK WASHER 5MM
608	P3616608	CONDUIT 20MM
609	P3616609	CONDUIT 15MM
610	P3616610	STRAIN RELIEF 20MM
611	P3616611	STRAIN RELIEF 25MM
612	P3616612	VERTICAL SWITCH BOX COVER
613	PFH31M	FLAT HD SCR M4-.7 X 8
614	PS08M	PHLP HD SCR M5-.8 X 12
615	PLW01M	LOCK WASHER 5MM
616	PW02M	FLAT WASHER 5MM
617	P3616617	VERTICAL SWITCH BOX
618	P3616618	VERT SPINDLE SWITCH M4D035
619	P3616619	COOLANT PUMP SWITCH M2C005

REF	PART #	DESCRIPTION
620	P3616620	E-STOP BUTTON LAY3-02ZS/1
621	P3616621	MAIN WIRING BOX W/LATCH
622	PSB33M	CAP SCREW M5-.8 X 12
623	P3616623	ELECTRICAL BOARD
624	PS09M	PHLP HD SCR M5-.8 X 10
625	P3616625	CONTACTOR CJX1-32/22 24V
626	P3616626	RELAY JR16-20/3D 10-16A 220V
626A	P3616626A	RELAY JR16-20/3D 20-32A 110V
627	P3616627	RELAY JR16-20/3D 0.32-0.5A 220V
627A	P3616627A	RELAY JR16-20/3D 0.68-1.1A 110V
628	P3616628	CIRCUIT BREAKER DZ47-63(1P,3A)
629	P3616629	LARGE TERMINAL BAR
630	P3616630	MICRO SWITCH
631	P3616631	SMALL TERMINAL BAR
632	P3616632	TRANSFORMER
633	P3616633	MAIN SWITCH W/KNOB
634	P3616634	STRAIN RELIEF 6.5MM
635	P3616635	STRAIN RELIEF 15MM
636	P3616636	STRAIN RELIEF 13MM
637	P3616637	CONDUIT 10MM
638	PLABEL-14	ELECTRICITY LABEL
650	P3616650	110V CONVERSION KIT



G3617 Electrical Parts Breakdown



G3617 Electrical Parts List

REF	PART #	DESCRIPTION
601	P3616601	HALOGEN LAMP
601-1	P3616601-1	BULB
601-2	P3616601-2	BULB COVER
601-3	P3616601-3	BULB COVER RETAINER
601-4	PS55M	PHLP HD SCR M3-.5 X 10
602	PSB33M	CAP SCREW M5-.8 X 12
603	P3616603	LAMP MOUNTING BRACKET
604	P3616604	LOCK WASHER 5MM
605	PN06M	HEX NUT M5-.8
606	P3616606	CAP SCREW M5
607	PLW01M	LOCK WASHER 5MM
608	P3616608	CONDUIT 20MM
609	P3616609	CONDUIT 15MM
610	P3616610	STRAIN RELIEF 20MM
611	P3616611	STRAIN RELIEF 25MM
612	P3616612	VERTICAL SWITCH BOX COVER
613	PFH31M	FLAT HD SCR M4-.7 X 8
614	PS08M	PHLP HD SCR M5-.8 X 12
615	PLW01M	LOCK WASHER 5MM
616	PW02M	FLAT WASHER 5MM
617	P3617617	VERTICAL SWITCH BOX
618	P3616618	VERT SPINDLE SWITCH M4D035
619	P3616619	COOLANT PUMP SWITCH M2C005
620	P3616609	CONDUIT 15MM
621	P3616610	STRAIN RELIEF 20MM
622	P3617622	HORIZONTAL SWITCH BOX
623	P3616623	MAIN WIRING BOX W/LATCH
624	PW02M	FLAT WASHER 5MM
625	PLW01M	LOCK WASHER 5MM

REF	PART #	DESCRIPTION
626	PSB33M	CAP SCREW M5-.8 X 12
627	PS07M	PHLP HD SCR M4-.7 X 8
628	P3617628	HORZ SWITCH BOX COVER
629	P3616618	HORIZ SPINDLE SWITCH M4D035
630	P3616620	E-STOP BUTTON LAY3-02ZS/1
631	PLW01M	LOCK WASHER 5MM
632	PS09M	PHLP HD SCR M5-.8 X 10
633	P3617633	ELECTRICAL BOARD
634	PS09M	PHLP HD SCR M5-.8 X 10
635	P3616625	CONTACTOR CJX1-32/22 24V
636	P3617626	RELAY JR16-20/3D 10-16A 220V
636A	P3616626A	RELAY JR16-20/3D 20-32A 110V
637	P3616637	RELAY JR16-20/3D 6.8-11A 220V
637A	P3616626A	RELAY JR16-20/3D 20-32A 110V
638	P3616627	RELAY JR16-20/3D 0.32-0.5A 220V
638A	P3616627A	RELAY JR16-20/3D 0.68-1.1 110V
639	P3616629	LARGE TERMINAL BAR
640	P3616630	MICRO SWITCH
641	P3616631	SMALL TERMINAL BAR
642	P3616632	TRANSFORMER
643	P3616633	MAIN SWITCH W/KNOB
644	P3616634	STRAIN RELIEF 6.5MM
645	P3616635	STRAIN RELIEF 15MM
646	P3616636	STRAIN RELIEF 13MM
647	P3616637	CONDUIT 10MM
648	P3616628	CIRCUIT BREAKER DZ47-63(1P,3A)
649	PLABEL-14	ELECTRICITY LABEL
650	P3617650	110V CONVERSION KIT

